
Xtratone Addressable Combined Sounder Beacon (MKII-AXTB/R & MKII-AXTB/W)





Description

The new Xtratone addressable wall sounder with beacon has been designed to make an "electronics free" first fix and is available in red or white. The beacon has a coverage pattern of W 3.0 - 8.9 and the sounder part has 16 tones selectable at the control panel.








Features


- 102dB @ 1m sound output
- 16 tones can be selected from control panel
- Flash rates between 0.33Hz and 1.5Hz
- Hard addressed via 8 way dip-switch OR
- Soft addressed via MKII Handheld Programmer
- Flush or surface fixing
- Moused in UL V0 flame retardant ABS
- 4 x 20mm cable entries (2 top, 2 bottom)
- First fix, wire to back box technology

Dimensions & Weight



Technical Specification

Model	MKII-AXTB/R	MKII-AXTB/W			
Part Number	42-617	42-618			
Operating Voltage	17 – 28V DC				
Quiescent Current	1.5	5mA			
Alarm Current	18 to	43mA			
Sound Output	96dB				
Colour	Red body, Clear Flash	White body, Clear Flash			
Minimum Continuous Operating Temperature	0°C				
Operating Temperature	-10°C To +55°C				
Max Humidity	95% Rh Nor	n Condensing			
IP Rating	IP:	21C			
Size mm (with back box)	105x 105 x 56mm (105 X 105 X 89mm)				
Weight	210g				




^{*} This applies to 'TONE 0' 800Hz and 970Hz, 500ms each

Xtratone Addressable Wall

Sounder (MKII-AXT/R & MKII-AXT/W)







The Xtratone sounders are small, high output addressable devices which are designed to meet EN54 part 3.

The device is a compact unit that fits a standard European back box and can be either surface or semi-flush mounted.

The Xtratone sounder has been designed so that field cables can be terminated in the back box as a first fix.







Features


- Complies to EN54 parts 3
- 100dB @ 1m sound output
- 16 tones** can be selected from control panel
- Hard addressed via 8 way dip-switch OR
- Soft addressed via MKII Handheld Programmer
- Flush or surface fixing
- Housed in UL V0 flame retardant ABS
- 4 x 20mm cable entries (2 top, 2 bottom)
- First fix, wire to back box technology

Dimensions & Weight

Technical Specification 42-610 42-611 Part Number Red White Colour Operating Voltage 17 - 28V Dc 17 - 28V Dc **Quiescent Current** 1.5mA Alarm Current 5.4mA Sound Output * 99.3dB +/- 2dB Minimum Continuous 0°C **Operating Temperature Operating Temperature** -10°C To +55°C Max Humidity 95% Rh Non Condensing IP Rating IP 21C Size mm 105 x 105 x 49mm (with back box) (105 X 105 X 82mm) Weight 200g

- * This applies to 'TONE 0' under reberberant conditions
- ** Approved tones are Tone 0 and Tone 8







ADDRESSABLE RAPTOR SOUNDER & SOUNDER BEACON INSTALLATION MANUAL









Description


The Raptor addressable sounder is a large weatherproof horn sounder suitable for many indoor & outdoor applications.

It is available in red or white and has a selection of 16 tones, selectable at the control panel

Termination of field wiring is made to the backbox for a clean first fix.


Connections - First Fix

The loop wiring connects to terminals in the back box.



Final Fix

- Set the device address (see address setting)
- Fix the BROWN sounder flying lead to the POSITIVE terminal
- Fix the BLUE sounder flying leads to the RIGHT NEGATIVE terminal
- Screw the sounder body to the backbox.



Address Setting

This sounder is addressed via an 8 way dip switch. All 8 switches are used for the address setting. It is a binary arrangement, with ON being the zero position.

Switch	1	2	3	4	5	6	7	8
Value when ON	0	0	0	0	0	0	0	0
Value when Off	1	2	4	8	16	32	64	128


The Switch settings can be calculated using these numbers. EG 21 = 16 + 4 + 1, so Switches 1,3 & 5 are off, all the others are on. The maximum address is 250. For convenience a table of all address settings can be found at the end of themanual.

Alternative Soft Addressing Option

Using our hand held MkII programmer (Part No: 48-004), the sounder can be addressed electronically.

Step 1: Set all addresses to zero 0000000

Step 2: Connect leads to LOOP IN+ and LOOP IN- as shown below



Step 3: Follow the procedure as described in the handheld programmer manual.

NOTE: When a device is soft addressed as above, the address CANNOT BE CHANGED by mechanical setting of the dip-switch. In order to re-enable the dip-switch the unit needs to be set electronically back to zero first.

Protocol Usage

The Raptor Sounder and sounder beacon work on the Zeta Fyreye II protocol only. The flasher (if fitted) can be triggered independently to the sounder, if the control panel supports that function.

Sounder Synchronisation

The Raptor sounders support the Fyreye II sounder synchronisation mechanism.

Alarm Tone Selection

The Raptor sounder supports alarm tone selection. IE, the installer can decide which alarm tone ALL the sounders will use. The alarm tone can be set for the whole system via the control panel. One of 16 tones can be chosen for the alarm tone.

No	Tone Description	Pattern	Frequency	Rate
0*	BS Fire (Default Zeta tone)	Alternating	800 & 970	1Hz (500ms-500ms)
1	BS Fire	Alternating	800 & 970	2Hz (250ms-250ms)
2	BS Fire	Sweep	800 to 970	1Hz (1 per second)
3	BS Fire	Sweep	800 to 970	7Hz (7 per second)
4	BS Fire	Sweep	800 to 970	50Hz (50 per
				second)
5	BS Fire	Alternating	510 & 610	1Hz (500ms-500ms)
6	German fire (DIN 33 404)	Sweep (DIN)	1200 to 500	1Hz
7	French fire (NFS 32-001)	Alternating	554 & 440	100ms-400ms
8*	Dutch fire (NEN 2575)	Slow whoop	500 to 1200	3.5s sweep, 0.5 s
				silence, then repeat
9	PFEER Toxic Gas	Continuous	970	Steady
10	PFEER alert	Intermittent	970	0.5Hz (1s On/1s Off)
11	Reserved	-	-	-
12	Reserved	-	-	-
13	Reserved	-	-	-
14	Reserved	-	-	-
15	Reserved	-	-	-

^{*} Approved Tones

See Document GLT-279-6-3 for further operational data.

Selecting a Reserved tone will cause the sounder to play tone 0. The default alarm tone will be tone 0.

Other Tones

The Raptor has 3 tones that can be triggered in normal running:-

- Alarm Tone Selectable see list above.
- Alert tone 970Hz intermittent. 0.5s on, 0.5s off
- Emergency 970Hz intermittent: 3 x 500ms pulses, 1.5s silence, then repeat

The availability of these tones will depend on the Control panel used.

Flasher Setting


The Raptor has a 4 way dip switch for configuring the flasher. Switches 1 to 3 configure the flasher as shown below. Switch 4 is for future use. Setting 1 gives the specified flasher rating.

Setting	Switch 1	Switch 2	Switch 3	Flash rate	Current	Relative Flasher intensity
1*	OFF	OFF	OFF	0.5 Hz	43mA	100%
2	ON	OFF	OFF	0.33 Hz	18mA	60%
3	OFF	ON	OFF	0.33 Hz	25mA	85%
4	ON	ON	OFF	0.33 Hz	33mA	99%
5	OFF	OFF	ON	0.5 Hz	33mA	89%
6	ON	OFF	ON	1.0 Hz	43mA	69%
7	OFF	ON	ON	1.5 Hz	43mA	46%
8	ON	ON	ON	OFF	5.4mA	0%

^{*} Approved Flasher setting

Beacon Coverage

The Raptor addressable sounder with beacon (ZRAPB/R & ZRAPB/W) has a coverage pattern of W-3.0-8.7 and an approved flash rate of 0.5 Hz.



Technical Data

Model	ZRAP/R	ZRAP/W	ZRAPB/R	ZRAPB/W	
Part Number	42-635	42-636	42-637	42-638	
Colour	Red	White	Red	White	
Flash Colour	N.	/A	White flash		
Flash Rate	N.	/A	0.33 - 1.5 Hz (depends on setting)		
Flasher Coverage	N.	/A	W-3.0-8.7 for setting 1		
Sounder Output (Anechoic)	82.9dB @1m				
Operating Voltage	17-28 V				
Quiescent Current	1.5 mA				
Alarm Current	5.4 mA max 19-44 mA (depends on setting			ends on setting)	
Sounder Type	Type B (outdoor use)				
Operating Temperature	-25°C to +70°C				
Minimum Continuous Operating Temperature	0°C				
Max Humidity	95% RH Non Condensing				
IP Rating	IP33C				
Size (H x W x D in mm)	146 x 150 x 98		146 x 150 x 107.5		
Weight (with Back Box)	540g		550g		

Minimum sound output 62.7dB

Troubleshooting

Problem	Possible Cause
Device Not Seen By Panel	Check the device is addressed within the range of the panel :-
	1 To 250 for a Quatro / 1 To 126 for a Simplicity Plus
	Other panels - check panel manuals for info
	Check that loop is connected with correct polarity
	Check that sounder flying leads have been connected to the backbox.
	Check the panel is running the Zeta Fyreye MkII protocol
Sounder Is Not Operating	Check panel`s actions (cause & effect) programming is correct.
Flasher is not operating	Check that the flasher LED wires have not been disconnected
	Check panel`s actions (cause & effect) programming is correct.
Can Not Start An Individual Sounder	Check whether triggering individual sounders is supported by the control panel
	Check the cause & effect programming to see if common operation has been selected